

86017 - RJ45 Plug field assembly Cat.5e PROFINET

<p>1 Package content <i>Packungsinhalt</i></p> <p>AWG 26 (0.5 - 6 mm)</p> <p>AWG 22 - 26</p>	<p>2 AWG 26 (if necessary / falls nötig)</p> <p>1 min. 25mm</p> <p>2 Stripping length <i>Abisolierlänge</i></p> <p>3 Fold braid shield backwards <i>Geflechtsschirm nach hinten legen</i></p> <p>4 Wrap braid shield evenly around cable jacket <i>Geflechtsschirm um das Kabel wickeln</i></p>	<p>3</p>	<p>4</p>	<p>5</p>
<p>6</p> <p>Delock 86033</p> <p>click</p>	<p>7 AWG 26 (if necessary / falls nötig)</p> <p>Remove the protective cover <i>Schutzabdeckung entfernen</i></p>	<p>8</p> <p>Lock Einrasten</p> <p>Slide cable forward until snap-in <i>Kabel nach vorne schieben bis zum Einrasten</i></p>	<p>9</p> <p>Lock Einrasten</p> <p>1. Turn strain relief to lock <i>Zugentlastung bis zum Einrasten drehen</i></p> <p>2. Tighten cable gland until stop <i>Verschraubung bis zum Anschlag anziehen</i></p>	<p>10</p>

Dismounting *Demontage*

<p>1</p> <p>Unlock Entriegeln</p>	<p>Face the latch downward <i>Rastnase nach unten anordnen</i></p> <p>Unlock Entriegeln</p>	<p>2</p> <p>Unlock Entriegeln</p>	<p>Unlock Entriegeln</p>	<p>3</p> <p>Unlock Entriegeln</p>
--	---	--	------------------------------	--

